

COMDIAL DXP/DXP PLUS TELEPHONE TIME CHANGE

1. PRESS INTERCOM AND DIAL * # 7 4 6 *.
2. PRESS 01.
3. ENTER IN THE TIME USING MILITARY FORMAT, HH/MM.
4. PRESS # TO SAVE.
5. PRESS SPEAKER TO COMPLETE PROGRAMING.